

PDU Utility

User Manual

Table of Contents

1. Introduction	1
2. Installation.....	2
3. PDU Utility Interface	4

1. Introduction

General

PDU Utility is PDU monitoring, management software. It has been designed to provide information about power conditions and status of PDU and power environment.


Its functions have

1. Monitor a large amount of PDU power consumption simultaneously.
2. Group Management of a large amount of the PDU.
3. Provide power consumption chart for daily monthly or the user-defined period report.
4. Send the email and trap to the specific account when the power event occurs.
5. Forward the trap to the user-defined account.
6. Events can be logged and exported to the Syslog server.

2. Installation


Install procedure:

CD Auto play screen. Please install the software step by step.




Note:

1. It will take several minutes if your operation system had not been installed Microsoft .NET Framework yet.
2. Recommend that install the Amazing PDU Utility to the server level of Windows operation system.
3. If install utility under [Windows Vista OS](#), you must first go to the folder of Amazing PDU and select the Properties of "Amazing PDU.exe", shown as below to check the "Run this program as an administrator". Then the utility will work normally.



First time to use Amazing PDU software, you must select what kind of database that you want to record the Amazing PDU information.

- The default database is set to Microsoft Access.
- If you want to use MySQL database, you may download it from <http://www.mysql.org>




3. PDU Utility Interface

Start

The Login Screen.


The default User Name is **admin**, Password is **1234**.



The screenshot shows a dialog box titled "PDU Login" with a blue title bar and a close button (X) in the top right corner. The dialog box has a light beige background. It contains two text input fields: "User Name:" and "Password:". Below the input fields are two buttons: "OK" and "Cancel".

After login to the software, you will see the software interface as following, it contains four sections:

1. **Function Menu:**
PDU Utility functions bar.
2. **PDU List:**
List all the PDU in the network; user can define the group to easily manage a large amount of the PDU.
3. **PDU Information:**
This area provides all detail information about the PDU.
4. **Device Summary:**
Indicate the status of the monitored PDU in the network.




Function Menu

Device

Add Device

Administrator can add the PDU by manually if the IP address of PDU had been setup before.



Device Group:

Select the PDU belongs to which group

SNMP Community:

Set the community, it must the same with the PDU in order to communicate with it. **Default setting is "private"**

Note1: This community is set for the authority of "WRITE".

Note2: The "READ" community is set to "public", and user can not change.

Trap forward IP:

When event occurs, it can forward the event trap to the certain NMS.

Syslog server IP:

Forward the log to the certain Syslog server.

Edit Device

Administrator can redefine the PDU information here,

including

The screenshot shows a 'Device Edit' window with the following sections:

- Local Settings:** Hostname: Amazing; Device Groups: (list box with 'group' selected); Community: private; Trap Forward IP: (empty); Syslog Server IP: (empty).
- SNMP Settings:** Name: Amazing; Location: Office; Contact: Admin; IP Address: 192.168.0.33; Modify button.
- Total Current Threshold Settings:** Warning Current: 10.0; Critical Current: 12.0.
- ENV Threshold Setting:** Temperature: Lower Bound: N/A, Upper Bound: N/A; Humidity: Lower Bound: N/A, Upper Bound: N/A.

Buttons: OK, Cancel.

Device Group: Change the Amazing PDU belongs to which group

SNMP Community: Set the community, it must be the same with the Amazing PDU.

Note: This community is set for the authority of "WRITE".

Trap forward IP: Change the trap receiver IP.

Syslog server IP: Change the Syslog server IP.

SNMP Settings: Modify the SNMP information for the Amazing PDU.


Network Settings: Re-defined the IP address of Amazing PDU.

Total Current Threshold Setting: It is only available when there is not only one PDU under this IP address.

User can input the current threshold to prevent total PDUs' power consumption exceed the facility capacity.

ENV Threshold Setting: When the temperature or humidity exceeds the pre-setting, utility will send mail to notify manager.

Manager can change the method that PDU Utility to get the IP.



Remove Selected Device

Delete the selected the IP address of PDU

Edit PDU Config

Modify PDU configuration.


PDU Name: User defines the PDU name.

Voltage: User defines the voltage..

Threshold: PDU Threshold.

Outlet Name: User defines the outlet name.

(Option)




Remove Selected PDU

Update Device Information

Update the PDU information manually.

Add Device Group


Create a new group.



The default group is named "Lab".

Edit Group

Rename the group



Remove Device Group

Delete an existing group. All PDU listed under this group must be removed first.

Data Management

Export kW*hr Account to CSV

Export power data with CSV format.

Export Data Log to CSV

Export current data log with CSV format.

Export Events to CSV

Export events data with CSV format..

Remove kW*hr Account Records

Delete power consumption data.

Remove Data Log Records

Delete current data log.

Remove Event Records

Delete event log.


System Management

Scan Subnet

Search all IP addresses of PDU that are connected under the same subnet.


Procedure:

1. Select the way to scan the PDU in the network.
 - Scan network interface subnet
 - Scan the specify subnet
2. Press the "Scan" Button to search all PDU devices under this subnet.
3. Checked the box of "ADD" that you want to add to PDU Utility.
4. Select one of the groups in the "Device Group" to category the PDU.
5. Select "OK" to finish the procedure.



General Setting


This setting contains two functions.



Mail:
When the event occurs, PDU Utility can send out the email message to the pre-defined account.

User List

Administrator can add, delete and manager all the user privilege here.




User can only change the password for the "Admin"

account.




Add user

User can be assigned to the authority of Read only or Read/Write.




Edit User:

Change the password, authority for the user.




Database Setting

Modify the database setting.



Service Control

Service control.



Note:





If the service can not start, it could be the SNMP port had been used by the other program in the Windows OS. Please close the program and then restart PDU.

PDU Information


Group Information:

List all PDU in this table and provide some important information.




Device Summary

-  Critical: Indicate output power of the PDU exceeds the setting of overload.
 -  Warning: Indicate output power of the PDU exceeds the setting of warning.
 -  Unreachable: Indicate that PDU Utility can not reach the PDU.
 -  Normal: Indicate the PDU is working normally.
- Service Status PDU Utility service status.

When indicates "Stopped" , please go to System Management> Service Control to "Start" the service.



The screenshot shows the PDU Utility software interface. On the left, a tree view displays the device hierarchy: All Devices, group, 192.168.0.54 (PDU-01), 192.168.0.77 (PDU-01), Rack, 192.168.0.62 (PDU-01), and Server. The main window displays the 'PDU Info' tab for the 'All Devices' group. It contains a table with the following data:

Icon	Name	IP	Group	Status	Update Time
	PDU	192.168.0.54	group	Normal	2009/6/17 上午 11:50:13
	Rack	192.168.0.62	Rack	Normal	2009/6/17 上午 11:50:13
	Server	192.168.0.77	group	Normal	2009/6/17 上午 11:50:14

Below the table, a 'Device Summary' section shows the following counts: Critical: 0, Warning: 0, Unreachable: 0, Normal: 3, and Service Status: Start.

Icon: Indicate the PDU status by different icon.

Name: The name of PDU.

IP:	The IP address of PDU
Status:	<p>Indicate the communication status with PDU Utility.</p> <ul style="list-style-type: none"> ● Normal: The PDU Utility communicates with PDU normally. ● Querying: The PDU Utility is requesting data from the PDU. ● Communication Lost: The PDU Utility can not get data from the PDU. ● Warning: The power consumption of PDU exceeds the threshold of warning. ● Overload: The power consumption of PDU exceeds the threshold of overload.
Update Time:	The last time of update PDU information.

Device Information:

Network Information:

Indicate the network and system information, Including


- IP Address
- MAC Address
- System Name
- System Contact
- System Location
- Trap Forward IP: Utility can forward the trap coming from the PDU to the given IP.
- Syslog Forward IP: Utility can send the log to the given IP which is syslog server.

General Information:

Indicate the detected information from total PDU device and attached device, Including

- Firmware Version
- Temperature
- Humidity
- Total Current: If this IP lists more than one PDU, utility can provide the function to accumulate all the

- current consumption under this IP.
- Device Warning: The warning threshold for all the current consumption under this IP.
- Device Critical: The critical threshold for all the current consumption under this IP.



The connected PDU information included:

Icon: Indicate the PDU status by different icon.

ID: The identification of PDU.

Name: The name of PDU

Status: Indicate the communication status with PDU Utility.

- Normal: The PDU Utility communicates with PDU normally.
- Querying: The PDU Utility is requesting data from the PDU.
- Communication Lost: The PDU Utility can not get data from the PDU.
- Warning: The power consumption of PDU exceeds the threshold of warning.
- Overload: The power consumption of PDU exceeds the threshold of overload.

Current: The PDU power consumption.

Time:	The current time.
Warning Current	Display the setting of PDU for warning threshold.
Overload Current	Display the setting of PDU for overload threshold.


PDU Information:

PDU System Information:

Provide the PDU information and status.

PDU Power Information:

Provide PDU power information; if the PDU support outlet control, you can click the hyperlink and enter to the PDU web page to control the outlet.



Power Consumption Chart:

Provide the chart for the PDU power consumption record.

Administrator can check the record by Daily, Monthly, Custom-defined time period.

Data Log:

Provide PDU current data and power record.

The screenshot displays the 'Data Log' window for a PDU unit. The interface includes a navigation pane on the left, a main data log area, and a 'Device Summary' section at the bottom left.

Navigation Pane:

- All Devices
- group
 - 192.168.0.54
 - PDU-01
 - 192.168.0.77
 - PDU-01
 - Rack
 - 192.168.0.62
 - PDU-01

Main Data Log Area:

Hostname: 192.168.0.54

Log Type: Current Power (kW/hr)

Log Time: Monthly Month: 2009/06 Custom From: 2009/06/17 To: 2009/06/17 Records per page: 30

Statistics:

- Average Current: 3.41 Amp
- Average Temperature: N/A
- Average Humidity: N/A

1 / 19 records displayed. Update button.

Date	PDU	Current	Temperature	Humidity
2009/06/17 11:51	1	2.30	0	0
2009/06/17 11:50	1	2.20	0	0
2009/06/17 11:49	1	2.20	0	0
2009/06/17 11:48	1	2.20	0	0
2009/06/17 11:47	1	8.00	0	0
2009/06/17 11:46	1	7.10	0	0
2009/06/17 11:45	1	7.10	0	0
2009/06/17 11:44	1	13.70	0	0
2009/06/17 11:43	1	7.50	0	0
2009/06/17 11:42	1	2.30	0	0

Device Summary:

- Critical: 0
- Warning: 0
- Unreachable: 0
- Normal: 3
- Service Status: Start

Events:

Provide events log.

The screenshot displays the 'Events' tab in a PDU management application. The interface is divided into several sections:

- Left Sidebar:** A tree view showing the device hierarchy: 'All Devices' (checked), 'group' (checked), '192.168.0.54' (checked), 'PDU-01' (checked), '192.168.0.77' (checked), 'PDU-01' (checked), 'Rack' (checked), '192.168.0.62' (checked), and 'PDU-01' (checked).
- Top Menu:** 'Device', 'Data Management', 'System Management', 'Help'. The 'Events' tab is selected.
- Filters:** 'Hostname: 192.168.0.54'. Filter type: 'Monthly' (selected) with 'Month: 2009/06'. 'Custom' filter is also visible with 'From: 2009/06/17' and 'To: 2009/06/17'.
- Events Summary:** A box showing 'Critical: 42', 'Warning: 137', and 'Unreachable: 0'. An 'Update' button is located to the right.
- Event Log Table:** A table with columns: Hostname, IP, Date, PDU, Event, and Cure. The table contains 13 rows of event data.
- Device Summary:** A box at the bottom left showing status counts: Critical: 0, Warning: 0, Unreachable: 0, Normal: 3. Service Status: Start.

Hostname	IP	Date	PDU	Event	Cure
N/A	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - add a ...	2.2
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Warni...	8
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Warni...	8
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Norm...	2.2
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Normal	2.2
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Warni...	9.6
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Warni...	9.6
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Norm...	2.3
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Normal	2.3
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Critical	8.4
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Critic...	8.4
Amazing	192.168.0.54	2009/6/16 上午 11:...	1	AmazingPDUService - Norm...	2.2

Report:

Provide data analysis.

1. Accumulated Power
2. Average Current
3. Average Temperature
4. Average Humidity

